

A DIVISION OF:
ACERBO'S AUTO TRIM
& LETTERING, INC.

ACERBOS.COM



Thank you for choosing our Camaro Vents for your vehicle!

We are committed to providing you with the highest level of customer satisfaction possible. If you see room for improvement, please let us know. We recommend professional installation for larger decals if you are unsure of your ability to install. If for any reason you have questions or comments, we would be delighted to hear from you. **Have a special request? You name it, we make it!**

LOCAL TO NEW JERSEY, USA? Check out our website WeStripeAnyCar.com for Professional Installation!

You can contact us at info@acerbographix.com or call at 856-273-8847

Please remember to check out the rest of our graphics in our store at www.AcerboGraphix.com.

Show us your final product! Take a photo and SEND it, POST it, or TAG us @acerbo_graphix on Instagram, and Acerbo's Auto Trim & Lettering on Facebook.

Again, thank you for your purchase. I hope you enjoy the product!

AcerboGraphix Team



Camaro Quarter Gill Decals (Vents) Installation Instructions

DF - Driver FRONT	PF - Passenger FRONT
DM - Driver MIDDLE	PM - Passenger MIDDLE
DR - Driver REAR	PR - Passenger REAR

Step 1: Clean area with alcohol to remove any wax and dirt.

Step 2: TEST FIT. This will allow you to see where the decal goes on the car and how you need to curve it to fit best. Location of decal is on the 1/4" flat of the vent. Some have found trimming the transfer tape closer to the graphic makes curving easier.

Step 3: Peel backing off gill decal.

Step 4: Start at the TOP of the gill and line it up with the FLAT of the vent, holding the bottom OUT from the car. Start pressing the decal onto the surface with your thumb, moving downward. Curve the decal as needed to match vent.

Step 5: Rub down firmly once entire vent is in place.

Step 6: Peel off the covering transfer paper from top to bottom carefully.

REPEAT for each of the remaining gill. Take a photo and share it with us!